




INSTRUCTIONS

HOW TO BUILD A DOOR SPACE






FOLLOW THE QUICKBLOCK INSTRUCTIONS WHEN BUILDING ENSURING ALL BLOCKS ARE LOCKED FIRMLY IN PLACE




USE HARD HATS, EYE PROTECTION, AND APPROPRIATE FOOTWEAR DURING CONSTRUCTION




BE AWARE OF FINGERTRAPS WHEN OPENING AND CLOSING THE BLOCKS, WE RECOMMEND USERS WEAR GLOVES WHEN BUILDING WITH QUICKBLOCK




DO NOT CONSTRUCT ABOVE 12 BLOCKS IN HEIGHT WITHOUT ADVICE FROM QUALIFIED PERSONNEL



FOR LONG WALLS, STRENGTHEN WITH RIGHT ANGLES BUTTRESSING (AT 2M INTERVALS) OR INTEGRATE ROOMS / CORNERS TO PROVIDE STABILITY



DO NOT CLIMB OR PLACE HEAVY LOADS ON QUICKBLOCK WALLS UNLESS RATED FOR IT.






WHERE POSSIBLE, CONSTRUCT ON LEVEL AND STABLE GROUND



AVOID USING BLOCKS IN WAYS NOT INTENDED BY THE MANUFACTURER. FOR MORE INFO, SEE THE INSTRUCTION MANUAL.



Open, click, build.



Opening blocks with excess force may result in blocks becoming damaged. It is recommended that blocks are opened with two hands and moderate force. QUICKBLOCK does not accept responsibility for blocks that are broken due to user error.

DOOR SPACE

Every place needs a way in. Creating a strong, stable opening for a door within a QUICKBLOCK structure is simple.

This door space is 912 mm wide x 2024 mm high.

To create the Lintel configuration required, please consult the dedicated instruction manual section and video.


Creating a wide variety of door sizes is made possible with QUICKBLOCK, this guide simply shows one example. To create a double-door opening for example, simply omit four blocks from the first layer instead of two (as explained in the guide), and ensure your Lintel* extends to the correct length of the span.



*To create the Lintel configuration required, please consult the dedicated instruction manual section and video.



STEP 1




The configuration of the bottom layer determines the location of the door space. Where desired, remove two **Full Blocks** from this layer.

The remaining opening represents the door width of 912 mm. When laying the second layer of blocks, two **Half Blocks** should be placed, one at each edge of the opening.


This will create straight, flush sides to the doorway.

STEP 2




Now, replicate this bricklaying pattern until the structure is nine layers high, remembering to use **Half Blocks** every second layer.

STEP 3



To finish, place a three-Block-length QUICKBLOCK Lintel structure* on top of the opening. The lintel should be placed such that it completes the bricklaying pattern, and the QUICKBLOCK **Capping Pieces** sit flush with the sides of the opening.

You now have a completed door opening.



*To create the Lintel configuration required, please consult the dedicated instruction manual section and video.



